

IVM

69 Madison Avenue • Telford, PA 18969 • (215) 723-3210

IVM **Midi Thruway** User Guide

General Remarks

The **Midi Thruway** unit is designed to act as a distribution box which directs one MIDI INPUT DIN jack to four MIDI OUTPUT DIN jacks.

Connecting the **Midi Thruway**

1. Remove the **Midi Thruway** unit and its power supply from the shipping container.
2. Connect the power lead, coming from the power supply, to the Power Jack located at the rear of the **Midi Thruway** unit.
3. Connect the MIDI Source cable which provides the MIDI data to be distributed to the MIDI IN DIN jack located on the rear of the **Midi Thruway**.
4. Connect up to four MIDI cables to the output jacks labelled THRU 1 to THRU 4. These cables are, in turn, attached to the various MIDI devices which receive the MIDI data which is present on the MIDI IN jack.
5. To complete your installation, plug the Power Supply into a standard 120 VAC 60 HZ outlet.

power chords
7TH CHORDS

power

7TH
13TH

BRASS KITS

DETUNE (+) OCT = 3, 2, 1, etc
 TONE MIX (PRESET)
 LEVEL 5
 PRESET NO. 12

4	PRESET
STRING ENS. /	

ORIENTAL SCALE

GREY SCALE

PATCH 18 - BLUES SCALE
 C Bb E F G A Bb C

PATCH 17 = ~~WESTERN~~ ORIENTAL SCALE
 ALL BLACK KEYS

78

61 63 66 68 70 73 75